



SeeMeCNC™
3D Printers & More



DropLit® v2 Resin 3D Printer User Guide

First Edition

v1.00 – June 29th, 2016

For nanoDLP

Copyright 2016 By Gene Buckle – geneb@deltasoft.com

Licensed as Creative Commons, Attribution-ShareAlike 3.0

Disclaimer text provided by LulzBot.

Official support is available through support@seemecnc.com

**As a new SeeMeCNC printer owner, you'll also find a ton of great resources on the
forums at forum.seemecnc.com**

READ ME FIRST!

READ THIS MANUAL COMPLETELY BEFORE UNPACKING AND POWERING UP YOUR PRINTER!

Hazards and Warnings

The SeeMeCNC Eris® Delta 3D printer has motorized and heated parts. When the printer is in operation always be aware of possible hazards.

Electric Shock Hazard

Never open the electronics bay of the printer while the printer is powered on. Before removing the access door, always power down the printer and unplug the AC line cord.

Fire Hazard

Never place flammable materials or liquids on or near the printer when powered on or in operation. Liquid acetone and vapors are extremely flammable.

Pinch Hazard

When the printer is in operation, take care to never put your fingers in the moving parts, including the belts, pulleys or gears. Also, tie back long hair or clothing that can get caught in the moving parts of the printer.

Static Charge

Make sure to ground yourself before touching the printer, especially the electronics. Electrostatic charges can damage electronic components. To ground yourself, touch a grounded source.

Age Warning

For users under the age of 18, adult supervision is recommended. Beware of choking hazards around small children.

Table of Contents

1 – Downloading Software.....	3
2 – Installing the Mini-Rambo Firmware.....	6
3 – Installing nanoDLP.....	10
4 – Configuring nanoDLP.....	12

1 – Supplies

Here's a list of recommended supplies to get you started with your new DropLit v2!

- Nitrile gloves. The resins used for 3D printing can be irritating to your skin so it's a good idea to wear gloves any time you're handling the resin, a freshly printed part, or a “wet” vat. These gloves can be purchased at nearly any auto-parts store for as little as \$8.
- Two ½ gallon plastic containers with sealable lids. These will be used as your wash and rinse “tanks”.
- 90% Isopropyl Alcohol. This is what you'll use to wash (and rinse!) your freshly printed parts with. You should get enough to fill your wash & rinse tanks half way.
- UV Curing Oven. Fancy name for a bright light. :) In order to fully cure your resin prints, they'll need to be exposed to strong UV light for a short period of time. There's two ways to accomplish this. You can purchase a UV Nail Dryer. This is normally used for curing fingernail appliques. Your other option is the DIY route. This is the route I took and what you'll see featured later on in this user manual. You can find a guide on building the same one I built here: <http://forum.formlabs.com/t/budget-uv-cure-box-jar/3176>. Take care to ensure that the jar you purchase is NOT made from polycarbonate. That material can block UV light. I would go with glass as you're sure of what you're getting. You can get a 1 gallon glass jar with a lid for around \$10.

2 – Downloading Software


Your new DropLit v2 3D printer utilizes two controllers. First is the Mini-Rambo controller. This device is what actually controls the stepper motor that moves the build platform out of the resin vat as the print progresses. It uses the SeeMeCNC version of Repetier Firmware.

The second controller is a Raspberry Pi 3. This device is what runs the nanoDLP software and in turn talks to the Mini-Rambo controller.

In order to start printing, you're going to need to install Repetier Firmware on to the Mini-Rambo and nanoDLP on to the Raspberry Pi 3.

You'll be downloading four packages and an ssh terminal program. The Mini-Rambo firmware, Arduino IDE, nanoDLP, a tool for writing SD card images, and a secure shell program for accessing the Raspberry Pi 3 directly.

The first download is for the Mini-Rambo controller. You'll want to go to SeeMeCNC's github repository and download the Mini-Rambo firmware – see <https://github.com/seemecnc/Firmware>. Click the **Clone or download** link and then on the **Download ZIP** button as shown below.



Downloading the Mini-Rambo firmware.

In order to compile the firmware and upload it to the Mini-Rambo, you'll need to head over to the Arduino website here: <https://www.arduino.cc/en/Main/Software> and download the installer for your platform. Keep in mind that this manual will only cover the Windows & MacOS installation procedures – the Linux process should be similar to that of MacOS.


DropLit v2 User's Guide

Next, you'll need to download nanoDLP itself. The nanoDLP download comes as an SD card image file that contains the operating system for the Raspberry Pi 3 as well as the nanoDLP software itself. Here's the nanoDLP download link: <http://www.nanodlp.com/nanodlp.zip>. If that download link doesn't work, just hit the main nanoDLP website at <http://www.nanodlp.com> and search for the **Download** link.

Now you'll need to download software that will allow you to write the nanoDLP SD card image to an SD card. For Windows users, you'll download a utility called Win32DiskImager and install it. Win32DiskImager can be downloaded from SourceForge:

<https://sourceforge.net/projects/win32diskimager/>

Click the green download link as shown below.



Win32DiskImager download link.

The SD card writing process for MacOS is more complex. Fortunately, the wonderful folks at the Raspberry Pi foundation have created an excellent tutorial for this process. You can find detailed instructions at the website link below. (I'll show that link again after you're done loading the Mini-Rambo with the software IT needs.)

<https://www.raspberrypi.org/documentation/installation/installing-images/mac.md>

The last program you need is a secure shell terminal program. This is needed to talk directly to the Raspberry Pi 3 instead of using the nanoDLP web interface. If you've already got an ssh program, great! If not, I highly recommend PuTTY. It can be downloaded here:

<http://www.chiark.greenend.org.uk/~sgtatham/putty/download.html>

There is no installer – it's a single stand-alone executable called **putty.exe**. I'll cover how to use PuTTY later.


DropLit v2 User's Guide

Unzip the firmware and nanoDLP files into their own directories and install the Arduino IDE and (in the case of Windows) the Win32DiskImager packages. Note that Win32DiskImager may ask to be run after the installer finishes. Untick the box for that and click OK. Win32DiskImager has to be run with administrative privileges in order to write out the SD card image. I'll cover that in a bit.

Next, we'll cover configuring the Arduino IDE and uploading firmware to the Mini-Rambo!

3 – Installing the Mini-Rambo Firmware


Start the Arduino IDE and then click on **Tools** and then **Board**. Select “Arduino/Genuino Mega or Mega 2560” as shown below.



Choosing the board to work with..

While the example above is from Windows, the MacOS **Tool** and **Board** options will be the same.


The next step is to select the port that the Mini-Rambo is using. In order to do that, you'll need to plug a USB cable into the Mini-Rambo, connect the power to the DropLit v2 and then turn it on.




Mini-Rambo, USB, and power connectors.

DropLit v2 User's Guide

In the Arduino IDE, click on **Tools** and then **Port**. Select the port that the Mini-Rambo is connected to. Chances are pretty good that it's going to be listed as something *other* than COM1.




Windows Port ID.



MacOS Port ID.

As you can see, the port for the Macintosh is identified as “/dev/cu.usbmodem211”. It may not be exactly the same with your system, but it will be close.

Now that we've gotten the Arduino IDE ready to go, we'll need to run a small program to clear the EEPROM on the Mini-Rambo. To load that program into the Arduino IDE, click on **File**, **Examples**, **EEPROM**, and finally on **eeeprom_clear**.




Loading the EEPROM clearing program.

DropLit v2 User's Guide

After the program is loaded, click on the **Upload** button as indicated below.

When you click the **Upload** button, the Arduino IDE will compile the `eprom_clear` program and then upload the result to the Mini-Rambo board. The process should only take a few seconds. When it's finished, you'll see a result that looks similar to the one shown below.




Done uploading.

Sketch uses 1,404 bytes (0%) of program storage space. Maximum is 253,952 bytes.
Global variables use 9 bytes (0%) of dynamic memory, leaving 8,183 bytes for local

Now it's time to configure the DropLit v2 firmware and get it uploaded to the Mini-Rambo!

The file you want to load is called **Repetier.ino** and will be found in the “Repetier” sub-directory where you unpacked the downloaded firmware.



Loading the firmware.

DropLit v2 User's Guide


Before you can upload the firmware to the Mini-Rambo, you'll need to make two changes to a file called **Configuration.h**. Click on the **Configuration.h** tab in the Arduino IDE. If that tab isn't visible, click on the small down-arrow to open a list of the files currently loaded in the Arduino IDE. You can pick **Configuration.h** out of that list.



Configuration.h tab.

Now scroll down a little until you see the section that matches the image below.

You need to make sure that the **MOTHERBOARD** definition is set to "302" for the Mini-Rambo and **PRINTER** is set to "4" for the DropLit v2. Now click on Save to save your changes.



```
41 // 301 = RAMBO    302 = MINI_RAMBO
42 #define MOTHERBOARD 302
43
44 /* Define Printer being used
45     Orion = 1
46     Rostock Max V2 = 2
47     ERIS = 3
48     DROPLIT = 4
49 */
50 #define PRINTER 4
```

Configuring the firmware.

Once the changes have been saved, you can click on the **Upload** button. Once the upload has completed, you're ready to write nanoDLP SD card image out to your SD card!


4 – Installing nanoDLP

If you're using MacOS, you'll need to follow the guidelines outlined here:

<https://www.raspberrypi.org/documentation/installation/installing-images/mac.md>


You'll use those instructions to write out the nanoDLP SD card image.

For Windows users, you'll use the Win32DiskImager utility that you downloaded earlier. Note that in order for Win32DiskImager to work properly, you'll need to run it as Administrator. You can do that by right-clicking on the Win32DiskImager program as shown below. (Note that the default install name for Win32DiskImager is “Image Writer”, not “SD Card Image Writer” as shown on Windows 10 example.



Running in Windows 10.


When you click on **Run as administrator**, you'll be prompted with a dialog box asking your permission to continue. Click on “**Yes**” to continue.



Running in Windows 7.

After Win32DiskImager starts, click on the folder icon to open the nanoDLP SD card image. Next, select the drive letter of the SD card you're going to be writing the image to. Make sure you've selected the correct device! To help avoid accidentally clobbering another device, it would be a good idea to remove any USB thumb drives or SD cards other than the one you're going to write to.


Click on the **Write** button to begin the writing process. The software will warn you to make sure you've chosen the correct device and will then begin the writing process once you allow it.



DropLit v2 User's Guide


When the process completes, eject the SD card from your system and insert it into the Raspberry Pi 3 as shown below. ***Please make sure you've turned off the power to the DropLit v2 before you do this!***

Note that it may be easier to install the SD card if you remove it from the DropLit v2 first.




If you removed the Raspberry Pi 3 to install the SD card, please re-install it now and we'll continue!

Replace the top to the DropLit v2 and connect the included USB cable from the Raspberry Pi 3 to the Mini-Rambo as shown.



SD card installed.



Mini-Rambo connected to the Raspberry Pi 3.


5 – Configuring nanoDLP

5.1 – Connecting to the DropLit v2

In order to communicate with the DropLit v2 the first time, you'll need to connect an Ethernet cable from your Internet router to the Raspberry Pi 3.


Power up your DropLit v2 and after about a minute, you'll be ready to access the printer.

If you're running Windows, you can open up Explorer and click on the **Network** item (most often found in the left side of the Explorer window.)



For MacOS users, you may be able to locate the DropLit v2 via the Network window in the Finder.

You're looking for an item that looks similar to the one shown on the right. It should be named NanoDLP. You can right-click on the icon to access it via your web browser.



If that icon doesn't appear, you can try the nanoDLP dashboard. This can be found at <http://www.nanodlp.com/dashboard>. If the nanoDLP dashboard can see the Raspberry Pi 3 in the DropLit v2, you'll see a page similar to the one shown below.

Available printers in your local network


Printer Interface
No Name

Last Seen
Recently

Progress
Setup "Online Access Key" to monitor progress

The nanoDLP dashboard page.

The first thing you'll want to do is check to see if there's an update available. If it's present, click the “**New Version Available**” button and follow the instructions it gives you.



The update should only take a few minutes and the Raspberry Pi 3 will be restarted when the update is finished. To check, refresh the web page after about 5 minutes.


5.2 – Expanding the Filesystem

After any updates have completed, the next task will be to expand the filesystem on the SD card to consume the available space. The nanoDLP SD card image is designed to fit on a 2GB SD card. However, the unit shipped with the DropLit v2 is 8GB. Expanding the filesystem will allow you to use all of that space for storing print jobs.

As you can see from the image on the right, the “disk” is at 80% of it's capacity.

CPU	25% (10)	Memory	2%
Disk	80%	Uptime	0m
Search			

You can easily expand the filesystem straight from the nanoDLP web interface. Simply click on the **Setup** button and then click on the **Tools** tab.



Expanding the filesystem.

Click on the **Expand Filesystem** button to begin the process. The process is actually pretty fast – give it about a minute and refresh your browser window. The statistics display should now show a lot more space available on the disk.

CPU	2% (9)	Memory	2%
Disk	10%	Uptime	0m

So much room for activities!

5.3 – Hardware Setup

Now it's time to configure nanoDLP to control the DropLit v2. Click on the **Setup** button and then click on the **Hardware Setup** tab (if it doesn't take you there by default).

Printer Name is pretty obvious. Pick whatever name you like!

For the parameters shown in the image below, there's nothing you need to change.



Printer Name ?

Gene's DropLit v2



Movement GPIOs
Does not required, if you are using separate controller
Step Pin for Z-Axis ?
Disable

3D Printer Board
Does not required, if you are using GPIOs to drive the printer

Shield Connection ? USB/Serial	Data Encoding ? Ascii	Shield Axis Direction Zero at Bottom	Calibration Buttons Positioning Relative
Wait Pin ? Disable	USB/Serial Port Path ? /dev/ttyACM0	Baud Rate 115200	Arduino i2c Address Restart Required 0

Note that if your configuration doesn't match what I show above, please change them to comply with what the image above shows.

The first parameter that needs updating is **GCode – Bootup**. Add the text below to that field.

G91

G1 Z.1 F100

G4 P100

Next is **GCode – Start of Print**.

G90 ; Put positioning in absolute mode

[[Delay 1.5]]

[[PositionSet 0]] ; Set current position on nanodlp so it could be recovered in case of failure

DropLit v2 User's Guide

If you're copying/pasting, please make sure you're not including the tabs. The text should be aligned along the left edge of the input field.

Next is **GCode – End of Print**.

M84 ;Disable Motors


;<Completed>



The screenshot shows four GCode configuration fields in a dark blue header. The 'GCode - End of Print' field contains the text 'M84 ;Disable Motors' followed by a new line and ';<Completed>'. The other fields are: 'GCode - Bootup' with 'G91', 'G1 Z.1 F100', and 'G4 P100'; 'GCode - Start of Print' with 'G90 ; Put positioning in absolute mode'; and 'GCode - Resume Print' which is empty.

Example showing correctly set fields.


Set the Shutter control to “**Disabled**”.



The screenshot shows the 'Shutter' control section. The 'Shutter Type' dropdown menu is open, showing three options: 'Disabled' (highlighted in blue), 'Servo Motor', and 'True/False Signal'.

Shutter disabled.

Set the resolution of your projector using the **Projector Resolution Width** and **Projector Resolution Height** fields as shown below. The values shown are correct for a “1080p” projector.



The screenshot shows the 'Projector' settings section. The 'Projector Resolution Width' field is set to '1920' and the 'Projector Resolution Height' field is set to '1080'. The 'Projector Control Type' dropdown menu is set to 'Disabled'.

Standard 1080p resolution settings.

The **Platform/Resin** settings should be set as you see below.



The screenshot shows the 'Platform / Resin' settings section. The 'Platform Wait Position' field is set to '10.000000' and the 'Resin Depth' field is set to '5.000000'. Both fields have a 'Millimeter' unit selector next to them.

Default Platform/Resin settings.

DropLit v2 User's Guide

The **Speed** settings for the DropLit v2 differ quite a bit from the default nanoDLP settings, so make sure you get them changed. Below are the correct values for the DropLit v2.

Speed

Max Speed <small>Micron/Second</small>	Min Speed	Motor Startup Speed
<input type="text" value="200"/>	<input type="text" value="100"/>	<input type="text" value="100"/>

New Speed settings.

The **Actuator/Motor** settings tell nanoDLP about the drive hardware & electronics used in the DropLit v2.

Actuator / Motor

Motor Step Angle	Microstep	Leadscrew Pitch <small>Millimeter</small>	Z-Axis Height <small>Pulse</small>
<input type="text" value="1.800000"/>	<input type="text" value="16.000000"/>	<input type="text" value="2.000000"/>	<input type="text" value="500"/>

Settings for the Mini-Rambo & DropLit v2's stepper motor.

Camera Module

Camera Photo Frequency

nanoDLP has support for using a camera to take photos periodically as the print progresses. This is a great tool to observe your print as well as the resin level in the vat. For now this feature is disabled – however if you obtain a camera that is compatible with the Raspberry Pi 3, this is how you can enable it for use with nanoDLP.

The remaining parameters are shown on the right. The defaults that ship with nanoDLP should be ok, but check to make sure they're set the same way.

Click on the **Submit** button on the bottom of the page to save your changes and we'll move on to the next tab!

LCD

LCD Type Restart Required

Physical Buttons

Stop/Shutdown Physical GPIO

Hardware Fault Detection

Stepper Driver Fault Detection Pin

Various Functions

Play Sound After Print Stop

DropLit v2 User's Guide

The default **Projector Mask** setting can be left as it is, so I won't cover it here.

5.4 – Customized Buttons

Click on the **Customized Buttons** tab. We've got a single button to add!

NanoDLP supports adding buttons to the user interface in order to perform special tasks. In this instance, we need to add a “Disable Stepper” button to the Z-Axis Calibration page. The figure below shows all the settings for the new button. The only data you'll need to type in is the button name, the Gcode, and the confirmation text. The other options are drop down selections.


Name / Color	Position / Condition	Syscall	Gcode	Confirmation Text	Action
<div>Disable Stepper</div> <div>Red</div>	<div>Z-Axis Calibration</div> <div>Idle</div>	<div>Program Path</div>	<div>M84</div>	<div>Stepper Disabled!</div>	<div>↑</div> <div>↓</div> <div>×</div>

When you're done, click the **Submit** button. You can see the new button in place if you click on the **Z Axis Calibration** link.



Z Axis Calibration link.


Below you'll see what the new button looks like!



Newly added button.



5.5 – Creating a Printer Profile

Printer Profiles in nanoDLP allow you to set a wide number of parameters to control resin cure times and layer thicknesses. Click on the **Printer Profiles** link and we'll get started!



The profile **Title** is pretty self-explanatory. I recommend that you use a similar format to what I show on the right – the name of the material and its color.

The **X/Y Resolution** parameter is one you'll need to calculate.

A screenshot of a form field labeled 'Title' in a dark blue header. The input area is white and contains the text 'MakerJuice SF/Orange' in a dark blue font.A screenshot of a form field labeled 'X/Y Resolution' in a dark blue header. To the right of the label are two small buttons: 'Micron' and a question mark icon. The input area is white and contains the text '88.000000' in a dark blue font.

Appendix A – Manually Expanding the Filesystem


In order to manually expand the filesystem on the Raspberry Pi 3, we'll need to connect to it via ssh. If you've used a ssh terminal before, you can just skim down to the login instructions.

For Windows users, I'll cover using PuTTY and for MacOS users, I'll cover using the ssh program from a terminal window.

First up, you'll need to know the IP address of your DropLit v2. You can find the IP address by looking at the address bar in your browser.

Windows

Start up PuTTY and enter the IP address of your DropLit v2 into the Host Name box. You'll want to make sure that “SSH” is ticked. Enter the name of your printer in the **Saved Sessions** box and then click the **Save** button.



Address example.

Click the **Open** button and it will open a terminal window and connect to the DropLit v2. Note that you may be prompted to accept a security certificate when you first connect – that's expected and it's okay to allow it. Enter “pi” as the login name and “raspberrypi” as the password. You can change this later if you like.

A screenshot of a PuTTY terminal window. The title bar shows "pi@raspberrypi: ~". The terminal output is as follows:

```
login as: pi
pi@10.1.10.22's password:

The programs included with the Debian GNU/Linux system are free software;
the exact distribution terms for each program are described in the
individual files in /usr/share/doc/*/copyright.


Debian GNU/Linux comes with ABSOLUTELY NO WARRANTY, to the extent
permitted by applicable law.
Last login: Fri Jul 1 17:11:06 2016 from 10.1.10.59
pi@raspberrypi:~ $
```

Connecting with PuTTY.

Macintosh

Open up a terminal window and enter in “ssh -l pi <ip address>” (without the quotes). Ex. “ssh -l pi 10.1.10.22”. The “-l” you see is a lower case letter “L”. This is required because without it, the ssh client will attempt to connect using your username. Since you don't have an account on the Raspberry Pi 3, you won't be able to log in.

Since this is the first time connecting, you'll be prompted to authorize the connection. Enter “yes” at the prompt. The default password for the “pi” account is “raspberry”. You can change this later if you like.




```
geneb — pi@raspberrypi: ~ — ssh -l pi 10.1.10.22 — 117x42
Genes-Mac:~ geneb$ ssh -l pi 10.1.10.22
The authenticity of host '10.1.10.22 (10.1.10.22)' can't be established.
ECDSA key fingerprint is SHA256:0uGaPzmEdhm3QfLTS0g7tnx0fLkQkMTaseM6Kn2NwVc.
Are you sure you want to continue connecting (yes/no)? yes
Warning: Permanently added '10.1.10.22' (ECDSA) to the list of known hosts.
pi@10.1.10.22's password:
The programs included with the Debian GNU/Linux system are free software;
the exact distribution terms for each program are described in the
individual files in /usr/share/doc/*/copyright.
Debian GNU/Linux comes with ABSOLUTELY NO WARRANTY, to the extent
permitted by applicable law.
Last login: Fri Jul 1 17:40:10 2016 from 10.1.10.59
pi@raspberrypi:~ $
```

Connecting with MacOS.

Now that you're connected, let's get that filesystem expanded, shall we?

Change to the **printer** directory by entering “**cd printer**” <enter> and then type in “**ls**” <enter> to bring up a directory of the files in the **printer** directory.



```
pi@raspberrypi:~ $ cd printer
pi@raspberrypi:~/printer $ ls
build          config  distro    install  NOTICE  public    templates
change-distro.sh db      expand-fs.sh LICENSE  printer  setup.sh  upgrade.sh
pi@raspberrypi:~/printer $
```

The thing we're after is called “**expand-fs.sh**”. This is a shell script that will start the process of expanding the filesystem on the SD card.

DropLit v2 User's Guide

Before we run that command, enter in “**df -h**”. This will show you the current amount of free space there is on the SD card, before we expand it.

The figure we're after is the “**/dev/root**” line. It shows we've only got 236MB of space free!

```
pi@raspberrypi:~ $ df -h
Filesystem      Size  Used Avail Use% Mounted on
/dev/root        1.2G  870M  236M   79% /
devtmpfs         427M    0  427M    0% /dev
tmpfs            432M    0  432M    0% /dev/shm
tmpfs            432M   12M  421M    3% /run
tmpfs            5.0M   4.0K   5.0M    1% /run/lock
tmpfs            432M    0  432M    0% /sys/fs/cgroup
/dev/mmcblk0p1   60M    20M   41M   34% /boot
pi@raspberrypi:~ $
```

Go ahead and execute the **expand-fs.sh** script by entering “**sudo ./expand-fs.sh**” and press Enter. The program will quickly do it's task and then reboot the Raspberry Pi 3. This will reset your connection of course, so you'll need to reconnect.

Check the free space as you did before – this time you can see that the root filesystem now has 14GB available. So much room for activities!

```
pi@raspberrypi:~ $ df -h
Filesystem      Size  Used Avail Use% Mounted on
/dev/root       15G  871M   14G    7% /
devtmpfs         427M    0  427M    0% /dev
tmpfs            432M    0  432M    0% /dev/shm
tmpfs            432M   5.8M  426M    2% /run
tmpfs            5.0M   4.0K   5.0M    1% /run/lock
tmpfs            432M    0  432M    0% /sys/fs/cgroup
/dev/mmcblk0p1   60M    20M   41M   34% /boot
pi@raspberrypi:~ $
```